

Tracer injected
into pipe

Residual contamination on pipewall




FIG.1




FIG.2




FIG.3




FIG.4




FIG.5




FIG.6




FIG.7

8/15




FIG.8




FIG.9




FIG.10




FIG.11




FIG.12




FIG.13





FIG.14



- a) Reactive tracer concentration curves when there is no contamination present.
- b) Reactive tracer concentration curves when contamination is encountered in the test zone

FIG.15